



**Dongguan Hust Tony Instruments Co.,Ltd**

**东莞华科东尼仪器有限公司**

Addr: No. 1 Tech 9 Road, High - New Tech Development Zone, Songshan Lake, Dongguan City 523808, China

Tel: 86-769-23010657

Fax: 86-769-23010667

Email: Addams@tonyhk.hk

### **Circular Sample Cutters TF-054-Direct Manufacturer**



Model	TF-054	
Control mode	Manual	
Cutting area	100cm <sup>2</sup> (conventional) ,50cm <sup>2</sup> ,10cm <sup>2</sup>	
Cutting thickness	0.1mm-10mm	
Machine size	15* 15* 15cm	
Blade size	Diameter:112.84mm (100 square centimeters)	
Package size	20*20*20*cm	
Net Weight	1.5 kg	
Gross weight	2kg	
Standards accessories	Spare blades	4 pcs
	Cutting mat	1 pcs

### **Features**

- 1.The fuselage adopts the one-time die-casting technology of labeled aluminum alloy, which overcomes the roughness caused by traditional steel casting and the defects of rust for a long time.
- 2.The cutter head is quenched and refined by special imported process, which has higher hardness and strength than the previous generation, and the accuracy error is only 1~2 wires
- 3.The blade of gold and steel is very sharp
- 4.Aluminum alloy body, strong and durable

### **Method of application**

- 1.Place the machine on a flat, hard and non-shaking workbench



**Dongguan Hust Tony Instruments Co.,Ltd**

**东莞华科东尼仪器有限公司**

**Addr:** No. 1 Tech 9 Road, High - New Tech Development Zone, Songshan Lake, Dongguan City 523808, China

**Tel:** 86-769-23010657

**Fax:** 86-769-23010667

**Email:** Addams@tonyhk.hk

2. Take out the special PVC backing plate and put it on the sampler tray
3. Place the textile fabric or paper to be sampled flat on the PVC pad
4. Take back your hand to hold the fuselage, lightly press the operating lever with the other hand, and release it lightly, and the sampling is completed

### **Precautions**

1. The PCV backing plate must be replaced frequently, otherwise the service life of the cutter head will be affected
2. The blade is extremely sharp, so be careful not to be cut when taking samples and backing plates
3. This is a professional machine, and minors under the age of 18 are prohibited from using it
4. Before cutting, please make sure that your hands are away from the knife, and there are only samples on the tray without debris
5. This is a single-person operation device, and it is forbidden for more than 2 people to use it at the same time to avoid accidents.