



Dongguan Hust Tony Instruments Co.,Ltd

东莞华科东尼仪器有限公司

Addr: No. 1 Tech 9 Road, High - New Tech Development Zone, Songshan Lake, Dongguan City 523808, China

Tel: 86-769-23010657

Fax: 86-769-23010667

Email: Addams@tonyhk.hk

Fabric Sample Cutters TF-054A-Strict Quality-Supplier



Fabric Sample Cutters TF-054A is used to cut all kinds of textiles, carpet, cardboard. Include: wool fabrics, cotton fabrics, manmade fabrics and knitting products.

Application : Textile, paper, leather, aluminum foil,ect.

Model	TF-054A	
Style	Adjustable, high-end style	
Manufacturing Materials	Aluminum alloy	
Cutting Area	50cm ²	
Cutting Thickness	0~12 mm	
Cutting Diameter	7.98cm	
Machine Size	128*135mm	
Package Size	20*20*20*cm	
Net Weight	1.5kg	
Gross Weight	2 kg	
Standards Accessories	Spare blades	4 Pcs
	Cutting mat	1 PcS

Features

- 1.The fuselage adopts the one-time die-casting technology of labeled aluminum alloy, which overcomes the roughness caused by traditional steel casting and the defects of rust for a long time.
- 2.The cutter head is quenched and refined by special imported process, which has higher hardness and strength than the previous generation, and the accuracy error is only 1~2 wires
- 3.The blade of gold and steel is very sharp
- 4.Aluminum alloy body, strong and durable

Method of application

- 1.Place the machine on a flat, hard and non-shaking workbench
- 2.Take out the special PVC backing plate and put it on the sampler tray
- 3.Place the textile fabric or paper to be sampled flat on the PVC pad
- 4.Take back your hand to hold the fuselage, lightly press the operating lever with the other hand, and release it lightly, and the sampling is completed

Precautions

- 1.The PCV backing plate must be replaced frequently, otherwise the service life of the cutter head will be affected
- 2.The blade is extremely sharp, so be careful not to be cut when taking samples and backing plates
- 3.This is a professional machine, and minors under the age of 18 are prohibited from using it
- 4.Before cutting, please make sure that your hands are away from the knife, and there are only samples on the tray without debris
- 5.This is a single-person operation device, and it is forbidden for more than 2 people to use it at the same time to avoid accidents.



Dongguan Hust Tony Instruments Co.,Ltd

东莞华科东尼仪器有限公司

Addr: No. 1 Tech 9 Road, High - New Tech Development Zone, Songshan Lake, Dongguan City 523808, China

Tel: 86-769-23010657

Fax: 86-769-23010667

Email: Addams@tonyhk.hk