



Dongguan Hust Tony Instruments Co.,Ltd

东莞华科东尼仪器有限公司

Addr: No. 1 Tech 9 Road, High - New Tech Development Zone, Songshan Lake, Dongguan City 523808, China

Tel: 86-769-23010657

Fax: 86-769-23010667

Email: Addams@tonyhk.hk

Fabric Sample Cutters TF-054B-Strict Quality-Supplier

Fabric Sample Cutters TF-054B is used to cut all kinds of textiles, carpet, cardboard. Include: wool fabrics, cotton fabrics, manmade fabrics and knitting products.

Application : Textile, paper, leather, aluminum foil,ect.



Model	TF-054B	
Style	Adjustable, high-end style	
Manufacturing Materials	Aluminum alloy	
Cutting Area	25cm ²	
Cutting Thickness	0~12 mm	
Cutting Diameter	5.64cm	
Machine Size	95*135mm	
Package Size	20*20*20*cm	
Net Weight	1kg	
Gross Weight	1.5 kg	
Standards Accessories	Spare blades	4 Pcs
	Cutting mat	1 PcS

Features

- 1.The fuselage adopts the one-time die-casting technology of labeled aluminum alloy, which overcomes the roughness caused by traditional steel casting and the defects of rust for a long time.
- 2.The cutter head is quenched and refined by special imported process, which has higher hardness and strength than the previous generation, and the accuracy error is only 1~2 wires

3. The blade of gold and steel is very sharp
4. Aluminum alloy body, strong and durable

Method of application

1. Place the machine on a flat, hard and non-shaking workbench
2. Take out the special PVC backing plate and put it on the sampler tray
3. Place the textile fabric or paper to be sampled flat on the PVC pad
4. Take back your hand to hold the fuselage, lightly press the operating lever with the other hand, and release it lightly, and the sampling is completed

Precautions

1. The PCV backing plate must be replaced frequently, otherwise the service life of the cutter head will be affected
2. The blade is extremely sharp, so be careful not to be cut when taking samples and backing plates
3. This is a professional machine, and minors under the age of 18 are prohibited from using it
4. Before cutting, please make sure that your hands are away from the knife, and there are only samples on the tray without debris
5. This is a single-person operation device, and it is forbidden for more than 2 people to use it at the same time to avoid accidents.



Dongguan Hust Tony Instruments Co.,Ltd

东莞华科东尼仪器有限公司

Addr: No. 1 Tech 9 Road, High - New Tech Development Zone, Songshan Lake, Dongguan City 523808, China

Tel: 86-769-23010657

Fax: 86-769-23010667

Email: Addams@tonyhk.hk